

05-12 Corvette UPR Oil Catch Can Installation

05-12 Corvette Assembly & Installation Instructions:

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
4. Install the bottom of the can to the top.
5. Install the 3/8 fittings into the side of the can.
6. Remove the factory passenger fuel rail cover.
7. At the passenger side front of the intake you will see an 11/32 hose going from the intake to the engine this is the crank case to intake vent, remove that hose.
8. Locate the bolt in the front of the passenger side cylinder head at the top, the only thing this bolt holds up is a ground wire.
9. Remove that bolt (13mm socket) from the head.
10. Using the provided bolt mount the catch can to the front of the head with the barbs facing the engine, the round spacer goes between the bracket and cylinder head. Make sure the ground strap stays attached to the head.
11. Connect the inlet side of the can to the engine valley cover port (**see picture below**) and the outlet side to the intake manifold.
12. Double check your connections, level the catch can and tighten the mounting bolt.
13. Press the fuel rail cover back into place.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Be sure to shop our online store for the best deals: www.uprproducts.com