

2011-2013 F-150 3.5L Driver Oil Catch Can Installation

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
4. Install the bottom of the can to the top.
5. Install the 3/8 fittings into the side of the can.



Disconnect the factory vent line by releasing the tab on each end and pull up.



Remove this nut on the top of the fan shroud.



Use the stud on the top of the fan mount the can. Secure with the factory nut you removed in previous step.



Install the factory Ford fittings on the provided hoses. Connect the inlet side of the can to the valve cover and the outlet side of the can to the intake.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE

Be sure to shop our online store for the best deals: www.uprproducts.com