

## 11-14 Mustang 3.7L V6 Catch Can Installation

### Instructions:

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
4. Install the bottom of the can to the top.
5. Install the 3/8 fittings into the side of the can.
6. Disconnect the factory vent line going from the intake down to the valve cover.
7. On the short hose provided push the straight OEM Ford fitting into one end.
8. Attached the other end of the short hose to the inlet side of the catch can and connect the fitting onto the valve cover.
9. Using the existing hole, mount the oil catch can to the top of the passenger side strut tower. See picture below.
10. On the long hose provided push the 90\* OEM Ford fitting into one end.
11. Attached the other end of the long hose to the outlet side of the catch can and snap the fitting onto the intake.



**NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE**

*Be sure to shop our online store for the best deals: [www.uprproducts.com](http://www.uprproducts.com)*